

Cutting Window Cling with the Cricut® Machine

1. Place window cling (liner side down) onto Cricut® cutting mat.
2. Select images and size and load mat into the machine.
3. Refer to Window Cling Kiss Cut Guide table to adjust machine settings. A kiss cut is a cut that only goes through the window cling and leaves the liner intact.
4. If cutting an intricate image, be sure you have checked “Mirror image” in the mat preview screen. This will allow you to use the liner to transfer the cut image to a surface.
5. Press CUT.

Application Instructions

1. Remove the negative pieces from each of the images using the Cricut® Weeder found in the Cricut® Tools Basic Set. This process is also known as weeding.
2. Peel the Cricut® Window Cling from the liner and apply by hand. Or, if you mirrored your images, use the liner to transfer the images to a clean and dry surface.
3. Burnish the window cling using the Cricut® Scrapper, also found in the Cricut® Tools Basic Set, to remove air bubbles.